


READER WIRING. T1. (RS485)

T7 is provided for connecting Inner Range SIFER Smart Card Readers or 3rd Party OSDP Readers. Refer to Reader Installation guides to check wiring details.



To extend the length of the Reader pigtail cable, twisted pair cable must be used:

Pair 1: Data A/B Pair 2: V+/0V. See Reader manual for details.

Reader Power Link Settings. (Check Reader Installation Manual)

READER	LK2/LK3
Inner Range Secure40 Prox Reader	12V
Omron Mag Swipe / HID Swipe / Insertion / Turnstile Wiegand Card Readers	5V
HID ProxPoint / MiniProx / ThinLine / iClass R10 / R15 / R30 / R40	5V
HID ProxPro. HID iClass R90 / RKL55	12V
Indala. SlimLine(Mullion) / WallSwitch / PinProx / ValueProx	5V
Indala. Standard / Mid Range 610 / MasterProx / Long Range 620	12V

NOTE: It is recommended that Readers with wide supply voltage ranges (e.g. 4V to 14V, 5V to 16V, etc.) are powered with 5V unless 12V is required for a longer read range.

Specifications

PCB dimensions: L: 200mm. W: 94mm H: Allow 45mm.
 Installation environment: 0° to 50°C. 15-90% relative humidity (non-condensing)
 Power Supply Input: 11V to 14V DC
 Current Consumption. 110mA idle. 175mA with both lock relays On (Unlock).
 Note. These figures do NOT include the current required by Readers or peripherals such as Lamps or Warning devices connected to the Lock, Valid, Invalid or DOTL outputs.
 Relay Contact rating. Lock: 5 Amps @30VDC. DOTL: 1 Amp @30VDC.
 Overcurrent Protection: 250mA. Self-resetting. +VR1/+VR2 are only used to supply (T4 +VR1 and T7 +VR2”) power to the Reader and associated LEDs and Piezo beeper.

This product uses components of FreeRTOS (see www.freertos.org).
 Source code for free RTOS can be obtained by download from www.freertos.org or by e-mail request to publications@innerrange.com.

Due to on-going product development this manual is subject to change without notice.

© 2013 - 2016. Inner Range Pty. Ltd.

Part No: 636018

Integriti
Intelligent LAN Access Module (ILAM)
P/N: 996018PCB&K
Installation Manual.

Overview


The ILAM supports up to 2 Doors, 2 Wiegand Readers, 8 Serial Readers (e.g. Salto, Aperio, etc.) or 16 Inner Range SIFER/OSDP compatible Readers via an RS485 Port. Up to 3 UniBus 2-Door/2-Reader Expanders may be connected to support a total of up to 8 Doors and 8 Wiegand Readers. SIFER/OSDP Readers allow Entry & Exit Readers on all 8 Doors. Using Wiegand/Serial Readers, up to 8 Doors can be used with single Readers but for each Door requiring Entry & Exit Readers, one less Door can be used. Heavy duty relays are provided for lock switching, along with a “DOTL Warning” relay and Open Collector outputs for “Valid” & “Invalid” to control LEDs and/or Sounders. The Module is supplied as a PCB and installation kit. An appropriate Integriti enclosure and power supply/s are chosen according to expansion and power requirements. See “Installation” on p2 for compatible enclosures. The Module may be powered from the LAN if adequate current is available from the power source, but a separate battery-backed power supply should still be used for lock power. Readers can be configured independently and integrated with Areas where required. Door Contacts and/or Tongue Sense inputs provide “Door Forced” and “DOTL” alarms.

IMPORTANT NOTES:

- 1) The Integriti Intelligent LAN Door Access Module is identified on the Integriti Controller LAN as an 8-Door Reader Module (I).
- 2) External battery-backed Power Supply is recommended and must be used if UniBus boards are connected. Choice of Power Supply will depend on Reader and Lock power requirements. The following suggestions are a guideline:
 - Module + 1 UniBus Board: Integriti 3A Smart Power Supply
 - Module + 2 or more UniBus boards: Integriti 3A or 8A Smart Power Supply
 Ensure that the current required by UniBus Boards and their peripherals does not cause the power supply current limit to be exceeded.
- 3) A separate battery-backed power supply is also recommended for Lock power. The Switched DC Power Hub (P/N:995916) can also be used to provided dedicated fuse protection for each Lock or each ‘Lock +/-’ input if required.
- 4) Integriti Software/ISC Controller Firmwate Compatability: V3.0 or later.
- 5) UniBus: A maximum of 6 UniBus Boards in total can be connected consisting of:
 - Up to 3 UniBus 2-Door Expanders. - Up to 2 UniBus 8-Relay Expanders.
 - Up to 6 UniBus 16-Floor Lift Interface Boards.


LAN Wiring

MODULE POWERED FROM INTEGRITI EXTERNAL SUPPLY (Recommended)



MODULE POWERED FROM THE LAN

* Note: If both “LAN +VE” wires provide a Power supply source, the one that is not required to power the Module must not be connected.




Zone Input, Button & DOTL wiring

Normally Closed contact.
- REED & TONGUE.
- REX & REN if “Override EOL” Disabled (default).

Normally Open Button contact.
- ARM button.
- REX & REN if “Override EOL” Enabled.

Normally Open DOTL Relay output.



Module Numbering

The Reader Module number is set using DIPswitches 1 to 7. The Module number equals $n + 1$, where n is the binary number set on DIPswitches 1 to 7.

Module No:	DIPswitch: 1	2	3	4	5	6	7
	Binary value: 1 2 4 8 16 32 64						
1	off	off	off	off	off	off	off
2	ON	off	off	off	off	off	off
3	off	ON	off	off	off	off	off
4	ON	ON	off	off	off	off	off
5	off	off	ON	off	off	off	off
6	ON	off	ON	off	off	off	off
7	off	ON	ON	off	off	off	off
8	ON	ON	ON	off	off	off	off
through to							
99	off	ON	off	off	off	ON	ON

Status and Fault LEDs

L1	RX.	Valid LAN packet received or LAN Fault indication. <i>See table below.</i>
L2	TX.	LAN packet sent or LAN Fault indication. <i>See table below.</i>
L3	FAULT.	On = LAN Fault. Refer to L1/L2 for fault details.
L4	SYS.	Flashing = Module is powered and firmware running OK.
L5/L6	Reader D0/D1	Data Receive indication for onboard Reader Inputs.
L10/L11	RX / TX	Data Tx/Rx indication for RDR RS485 connection.
L12/L13		“+VR1” / “+VR2” Fault indication. e.g. Over current.
L14	UniBus	Flashing Idle. No UniBus cards connected.
		Off OK. UniBus Card/s communicating correctly.
		On Fault. Problem with one or more UniBus Cards. e.g. Address conflict.
L16/L17		Lock 1 / Lock 2 Relay On indication.

L1	L2	EXPLANATION / REMEDY
ON	ON	Module is un-addressed. (Not communicating with the Controller)
ON	OFF	Too many Modules on the Network. Check limits and licencing.
OFF	ON	Module type unknown. Controller firmware upgrade required.
Flash	ON	Duplicate Module. Number already in use by module of the same type.
Flash	Flash	Module number selected is too big. Select a lower Module number that is not already in use or check limits and licencing.
OFF	Flash	Module disabled.

Note: If a firmware update is performed, the internal memory may need to be erased. This will be indicated by L1/L2/L3=Off, L5/L6=On and it may take up to 1 minute for the Module to resume normal operation.

T11. Earth Lug.

Refer to "Installing the Module" on p2.

T1. RDR RS485.

Connection for Readers with RS485 output format. Refer to page 8 & RS485 Reader installation guide.

P1. External Power.

(Does not provide Lock Power) Connects to:
 - An Integriti Power Supply using the cable provided with the PS.
 - A 3rd Party Power Supply using cable P/ No: 996794 (500mm)

T10. Lock +/-.
 Power input for "Lock+/-" on T2 & T5.

T2 / L16. Lock 1 Relay & indicator LED.

See Page 7 (Lock Wiring) & Page 8 (Electrical Specs)

T3. Door 1 Input / Output connections.

See "Zone Input, Button & DOTL wiring" on p6.

- REED Reed Switch Input. EOL resistors required.
- 0V 0 Volt return for Input connections.
- TONG Optional Tongue Sense I/P. EOL resistors required.
- REN Entry Button I/P. EOL Resistors Optional.
- REX Exit Button Input. EOL Resistors Optional.
- DOTL "DOTL Warning" Relay output. If connecting to Reader Beeper wire, connect other contact to 0V.

LK1. TERM.

Reader RS485 Termination. Refer to Reader installation guide.

- RS485 RX (L10)** See Page 3.
- RS485 TX (L11)** See Page 3.

DIPswitch SW1: Switch 1-7.

Module number. See table on p3.

- L1** LAN Data Receive / Fault indication.
- L2** LAN Data Transmit / Fault indication.
- FAULT** LAN Comms Problem. See table on p3.

P2 / L14. UniBus.

Connector & Status LED for UniBus boards. e.g. 2-Door Exp., 8 Relay Exp. or Lift Exp.
NOTE: An External Power Supply must be connected to P1 if any UniBus boards are connected. See notes on pages 1 and 3.

T9. Tamper Switch Connection
 See "Installing the Module" on page 2.

P5. Ancillary LAN connection.

T8. Integriti LAN connection.
 See "LAN Wiring" on page 6.

LK2 / L12
LK3 / L13.
 Reader Supply voltage; 5V / 12V and Fault LED.
 See details on page 3 and page 8.


T7. Reader 2 connection
 See T4 for details.

- D0 (L5).** Data 0's I/P either Reader.
- D1 (L6).** Data 1's I/P either Reader.

T6. Door 2 Input/Output connections. See T3 for details.

SYS. L4.
 Flashing = OK. See Page 8 for details.

T5 / L17. Lock 2 Relay & indicator LED. See p6 (Lock Wiring) & p8 (Specs)



- T4. Reader 1 connections.** See "Reader Wiring" on p7.
- VAL Reader "Valid" LED output.
- INV Reader "Invalid" LED output.
- 0V Reader 0 Volt (-ve) connection.
- +VR Reader power supply.
- D1 (CLK) Reader Data or Clock input.
- D0 (Data) Reader Data input.
- ARM Button Input for optional Area ON control. EOL resistors NOT required.